SeaEra

FLOOR TEMPLATE


MODELS: 160HI0** and 160MI0**

(**: VOLTAGE 12, 24 or 32)

MPORTANT:


INSTRUCTIONS FOR PRINTING AND ASSEMBLING TEMPLATE.


- 1. Template is PDF format, for 8 1/2 x 11" paper.
- 2. Page Scaling: Select 'NONE' (MUST PRINT FULL SCALE)
- 3. With scissors, cut on 'Dashed Lines'. See — —
- Align sheets accordingly using Dashed Lines and corresponding Alignment Arrows and tape together.
- at the CHECK POINT on template (lower left). You should measure 7" Check that printed template is the correct scale (size) by measuring



IMPORTANT:

- 1. DO NOT DRILL OR CUT HOLES FROM THIS TEMPLATE. FOR REFERENCE ONLY
- 2. REFER TO INSTALLATION MANUAL FOR INSTALLATION DETAILS.
- 3. CHINA BOWL DIMENSIONS CAN VARY +/-5%. CONSIDER THIS WHEN INSTALLING
- 4. DIMENSIONS ARE: INCHES [MM]





WWW.RARITANENG.COM

SHEET 1




Seatra


**: VOLTAGE 12, 24 or 32


THIS TEMPLATE SHOWS THE LOWER BASE ASSEMBLY IN THE STANDARD POSITION

AND ROTATED 90 DEGREES









SHEEL 4

