
IN LINE FUSE NOT INCLUDED
12 VOLT 3 AMP
24 VOLT 2 AMP
32 VOLT 2 AMP
NOTE:
MOTOR IS INTERNALLY GROUNDED THEREFORE BATTERY POLARIZATION IS NOT NECESSARY.
DO NOT WIRE THRU SWITCHBOARD WIRE DIRECTLY TO BATTERY CIRCUIT BREAKER.
MOTOR
Red Wire
BONDING TERMINAL
Orange Wire
SOLENOID
MOTOR WIRING
12 VOLT USE #6 WIRE
32 VOLT USE #8 WIRE
115/230 V.A.C. USE #12 WIRE
BATTERY
12 VOLT - 60 AMP.
24 VOLT - 30 AMP.
32 VOLT - 30 AMP.
CIRCUIT BREAKER
IN POSITIVE SIDE OF LINE
#12 STRANDED WIRE
TO MANUAL SWITCH
RAZ MARINE
(954)525-5513


IN LINE FUSE NOT INCLUDED
12 VOLT 3 AMP
24 VOLT 2 AMP
32 VOLT 2 AMP
NOTE:
MOTOR IS INTERNALLY GROUNDED THEREFORE BATTERY POLARIZATION IS NOT NECESSARY.
DO NOT WIRE THRU SWITCHBOARD WIRE DIRECTLY TO BATTERY CIRCUIT BREAKER.
MOTOR
Red Wire
BONDING TERMINAL
Orange Wire
SOLENOID
MOTOR WIRING
12 VOLT USE #6 WIRE
32 VOLT USE #8 WIRE
115/230 V.A.C. USE #12 WIRE
BATTERY
12 VOLT - 60 AMP.
24 VOLT - 30 AMP.
32 VOLT - 30 AMP.
CIRCUIT BREAKER
IN POSITIVE SIDE OF LINE
#12 STRANDED WIRE
TO MANUAL SWITCH
RAZ MARINE
(954)525-5513